


MODEL : SOVO DOUBLE (16 PCS SLAT)
ASSEMBLY INSTRUCTION

HARDWARE LIST

| | | | | | | |
|---|--------|------|--------|------|--------|------|
| 1 | 1 PC | 1 PC | 1 PC | 1 PC | 1 PC | 1 PC |
| 2 | 8 PCS | 2 | 8 PCS | 2 | 8 PCS | 2 |
| 3 | 8 PCS | 3 | 8 PCS | 3 | 8 PCS | 3 |
| 4 | 48 PCS | 4 | 48 PCS | 4 | 48 PCS | 4 |
| 5 | 4 PCS | 5 | 4 PCS | 5 | 4 PCS | 5 |
| 6 | 8 PCS | 6 | 8 PCS | 6 | 8 PCS | 6 |
| 7 | 6 PCS | 7 | 6 PCS | 7 | 6 PCS | 7 |



PART LIST

| NO | DESCRIPTION | QTY |
|----|--------------------|-------|
| A | HEADBOARD PANEL | 1 PC |
| B | FOOTBOARD PANEL | 1 PC |
| C | SIDE RAIL | 2 PCS |
| D | SLATS | 1 SET |
| E | CENTER SUPPORT | 1 PC |
| F | CENTER SUPPORT LEG | 3 PCS |

When assembling, do not tighten all screws until all section are assembled.
 Always remember to assemble furniture on a clean, smooth and carpeted surface.